# REXING

# **V5C Plus** Quick Start Guide

The information in this manual is subject to change without notice. Rexing All Rights Reserved

www.rexingusa.com

012024REV1

# Activate Your 18-Month Warranty & Choose Your FREE Gift!

Activate within 30 days of purchase to claim your free gift and extend your limited 12-month warranty to 18 months.

Scan The QR To Activate & Select Your Free Gift

SCAN



 $\mathbf{O}\mathbf{Z}$ 

https://www.rexingusa.com/productreg/

# Overview

### Thank you for choosing REXING!

We hope you love your new products as much as we do. If you need assistance, or have any suggestions to improve it, please contact us.



care@rexingusa.com



(877) 740-8004

Our support team will respond you as soon as possible.

Always a surprise in Rexing.

#### Check us out here

- https://www.facebook.com/rexingusa/
- https://www.instagram.com/rexingdashcam/
- https://www.rexingusa.com/support/registration/
- https://www.rexingusa.com/support/product-support/















1. What's in the box



- 1. Rexing V5C Plus Dash Cam
- 2. 64GB Micro SD Card
- 3. Car Power Connector (12ft)
- 4. 3M Adhesive Mount
- 5. Cable Management Kit

- 6. Quick Start Guide
- 7. Safety Guide
- 8. Warning Sticker
- 9. Electrostatic Sticker

# 2. Camera Overview



- 1. Power Button / Screen Toggle Button
- 2. Menu Button / Mode Button
- 3. Up Navigation Button / Screen View Button/ WiFi On-Off Button
- 4. Down Navigation Button / Mute Button/ GPS Info Button
- 5. OK (Confirm) Button / Record Button/ Emergency Lock Button
- 6. USB Charging Port
- 7. Micro SD Card Slot
- 8. Rear Camera Port (rear camera sold seperately)
- 9. Cabin-facing camera

#### Screen Icons



# 3. Installation

# Step 1

### Installing the Electrostatic Stickers

#### 1.1 Prepare Your Windshield

Thoroughly cleanse your windshield with either water or alcohol, Follow this by wiping it dry using a clean, dry cloth to ensure a spotless surface. 1.2 Position the Sticker

Next, carefully peel off the protective film from the electrostatic sticker. Attach the sticker to the windshield, ideally behind the rear-view mirror. This position is recommended to avoid obstructing your view while vou're on the road.



# Step 2

### Install the Dash Cam

Place the 3M tape on the mount and properly orient the mount square to the roof and hood line of the vehicle

#### Secure the Mount and Camera

Now, remove the 3M tape from the mount. Once done, you can proceed to fix both the mount and camera onto the previously positioned electrostatic stickers

Important! Ensure the T-interlock on the mount is oriented in the correct direction. Firmly press the Mount onto the windshield. Wait at least 20 minutes before mounting the camera.

On the illustration Orient the mount as shown.



#### Step 3

#### Insert the Memory Card

The Rexing V5C Plus accepts Class 10/UHS-3 or higher Micro SD memory cards up to 256GB. You will need to insert a memory card before you can begin recording. Before inserting or removing a memory card, first ensure you've powered down the device. Gently push the memory card in until you hear a click, and allow the spring release to push the card out.



#### Power on the Camera and Format the Memory Card

Power on the camera by connecting the charger to the car cigarette lighter and camera. To ensure the VSC records to your memory card properly and without error. Before you start using a new memory card, you must format the card within the camera using the format function. Always backup important data stored on the memory card before formatting.

To format the memory card, make sure you have inserted your memory card, then turn on the device by connecting to a power source. Press **OK** to stop recording. Then press the **MENU** button twice to enter the System Setup Menu. Use the **A** and **S** buttons and toggle to the Format setting. Press the **OK** button to confirm the selection.

You may now disconnect from power. The camera will shut down after 3 seconds. The camera should begin recording automatically the next time it is powered on.







### Mount the Rear Camera (optional)

#### Rear cam needs to purchase separately.

Mount the rear camera as shown below. Use rear camera cable to connect the rear camera to the V5C Plus camera.







#### Installing the Camera onto the Windshield

Place the camera on the mount and carefully route the power cable around the windscreen and tuck in under the trim.

Plug the Car Charger Cable into a 12V DC power outlet or the car cigarette lighter. Connect car charger to the camera. The camera will auto-start recording once powered on.

Route power cable to the Dashcam



Plug Mini USB Connector to the Dashcam



Plug charger into power outlet or cigarette lighter



# 4. Basic Operation

### **Device Power**

The device is automatically powered on when plugged into a 12V accessory socket or cigarette lighter and received a charge (i.e. the vehicle is started).

To turn the device on manually, press and hold the **Power** button until the welcome screen appears.

The camera will automatically start recording when power on.



to turn the device on manually

#### **Menu Settings**

Power the camera on. If the camera is recording, press the  $\ensuremath{\text{OK}}$  button to stop recording.

Hold the **MENU** button and toggle to the desired mode. Press the **MENU** button once to enter the settings menu for a Mode. Press the **MENU** button twice to enter the System Settings (Set up).

#### Video Recording

The camera will automatically start recording when the device receives charge. The LED lights and red dot will blink device when recording. Press the **OK** button to stop recording.



The camera automatically starts recording when powered on

### EMR Mode (Locked Video)

To use the Emergency Record Mode, hold the **OK** button to manually record a 20 second video that is automatically saved and locked.

View EMR recordings by pressing the menu/playback button.

#### Video Playback

Playback of videos can be done on the device or a computer. To playback a video on the device, toggle to the Playback mode. Use the 🚺 and 🔽 buttons to toggle to the desired video. Press the **OK** button to play.

During playback use the **OK** (pause), **(rewind)** and **(fast forward)** buttons to control the video playback.

To playback a video on the computer, either use an SD card adapter or connect he device to the computer directly using the USB cable.

To playback a video using an SD card adapter, remove the memory card and insert it into an SD card adapter. Place the adapter in the computer.



## Wi-Fi Connect

#### Step 1

With your dash cam powered on, hold the **UP** Navigation button to enable the Wi-Fi function. The Wi-Fi name (aka the SSID) and password for the dash cam should be displayed on-screen.



#### Step 2

On your mobile device, navigate to your Wi-Fi settings. Connect to your dash cam's Wi-Fi by tapping its name when it appears. Enter your dash cam's Wi-Fi password if you are prompted to do so.

Note: On same mobile devices, you may have to try to connect more than once. To ensure you've successfully connected, your mobile device's screen should resemble the examples shown.



Once you're connected to the dash cam, open the Rexing Connect app on your mobile device.

Please select "Keep Trying Wi-Fi" if you see the notification on the right.



#### Step 4

In the app, hit the "Connect" button to connect to your dash cam, allowing you to access live view and view/download your recordings.

Note: Hold to the UP button for 2 seconds to disconnect the Wi-Fi.

## **Rexing Connect App**

Easily download the app by scanning the QR code below or search via the App Store or Google Play.



#### Wi-Fi Connect Troubleshooting

If you bring up the Rexing connect app and cannot connect your phone to the dash cam please go to <a href="https://www.rexingusa.com/wifi-connect/">https://www.rexingusa.com/wifi-connect/</a> OR scan the QR code below.



# **GPS Logger**

You can then access this information while playing back your recordings using the GPS Video player (For Windows and Mac, available at rexingusa.com).

The dash cam will automatically search for the GPS signal once it's connected to the power source. Press the **MENU** button twice and go to System Settings. Toggle the GPS Speed Unit setting, and select your favorite speed unit.

After a GPS signal is found, the screen icon will turn from red to green as per the below icons. It will record the speed and location of your vehicle as you drive.



GPS function active



GPS Signal (not found)

#### **GPS Date-Time Troubleshooting**

If your dash cam GPS data and time are incorrect please to https://www.rexingusa.com/gps-data-time/ OR scan the QR code below.



### Voice Command

Below is a list of voice commands that you can use to carry out system functions hands-free. The device will not recognize a command that is not included in the following list:

Ō	Take Photo	
۲	Video Start	
0	Video Stop	
4	Turn on Audio	
∢×	Turn off Audio	
Q	Turn on Screen	
Ē	Turn off Screen	
Ś	Turn on WiFi	
Ŕ	Turn off WiFi	
-	Show Front Camera	
۲	Show Rear Camera	
1	Show Both Cameras	
4	Lock the Video	
<b>[•</b> ]	Inside Video on	

### Parking Monitor (Parking Surveillance Mode)

Parking monitor provides surveillance on your parked vehicle. When the engine is off, the hardwire kit is used to provide continuous power and protect your car battery from being discharged.

#### **Option 1: Vibration Detection**

To enable the Parking Monitor, you'll need to connect it with a Smart Hardwire Kit (sold separately).



This feature will allow the dash cam to switch to parking mode automatically if the vehicle's engine turns off and switch back to the normal recording after the vehicle's engine turns on.

#### Gravity Sensing Record:

The Gravity Sensing detects significant or sudden movement (such as an impact or collision), it will trigger an event recording. We suggest setting the "Gravity Sensing" to High sensitivity for Parking Mode Recording.

#### Note:

If you do not use the parking mode function, please change the Gravity Sensing sensitivity to low. Otherwise, the video will easily be locked and the video cannot be deleted by the loop recording function. This will cause the memory card to be full of locked videos and cause the recorder to fail to work normally.

Please DO NOT ENABLE the Parking Monitor function in the settings of the dash cam WITHOUT connecting a smart hardwire kit. They may cause a malfunction.

#### **Option 2: Motion Detection**

To use this feature, you need to connect it with a Rexing Intelligent Hardwire Kit (sold separately). Make sure that the Parking Mode is turned off on your dash cam, otherwise it may cause a malfunction.

Once the sensor has detected MOTIONS. The intelligent hardwire kit will power up the dash cam automatically and start recording until the MOTION is cleared.

Please go to https://www.rexingusa.com/hwk-install/ to watch a video tutorial about the installation or

to watch a video tutorial about the installation or scan the QR code below.



### **Taking Photos**

To take a photo, Please use "take phote"voice command.

To view a photo, stop video recording and hold on **MENU** button to the Playback Mode.

Press 🚺 the 🔽 and Buttons to toggle through your photos.

To delete a photo, stop video recording and toggle to the Playback Mode and toggle through the videos and photos to the one you want to delete. Press the **MENU** to toggle the Delete option.

Press the OK Button and select Delete Current or Delete All.



Toggle to the Playback mode and select a photo to view



Toggle to the Delete option



Choose the desired option

# Warranty & Support

## Warranty

The Rexing V5C Plus Dash Cam comes with a full 12-month warranty. If you register your product on our official site (https://www.rexingusa.com/support/registration), you can extend the warranty to 18 months.

# Support

If you have any questions regarding your product, please do not hesitate to contact us at care@rexingusa.com, or call us at (877) 740-8004. Queries are typically answered within 12-24 hours.

#### Your opinion matters

Rexing is firmly committed to always improving our products, services, and user experience. If you have any thoughts on how we can do even better, we welcome your constructive feedback and suggestions.

Connect with us today at care@rexingusa.com

Thank you for choosing Rexing!

#### FCCID: 2AW5W-V5C

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.



MADE IN CHINA