



# VeSee Manual

## 1. VeSee Player Manual



- 1) version detection: click the test version upgrade.
- 2) play mode: play mode switch.
- 3) increase: increase play video.
- 4) delete: delete a single video.
- 5) clear list: clear list of video files.
- 6) help: player instructions.
- 7) minimize: video playback.
- 8) maximize: maximize player display.
- 9) close: close player.
- 10) hidden list: hide playlist.
- 11) the last one: play a video.
- 12) pause / play: pause / play video.
- 13) the next: play the next video.
- 14) stop: stop playing video.
- 15) the following: the video playback for the camera recording down.
- 16) on: the video for the camera to record.
- 17) before: video playback for the camera to record.
- 18) 2 sub screen: display of the video angle of the 2 screen (front / back).
- 19) 4 sub screen: display the video angle of the screen for 4 minutes (front / back / left / right).
- 20) wide angle: show the video angle is wide angle.
- 21) update calibration: update calibration video angle size.
- 22) volume: adjust the volume size.
- 23) conversion: the conversion of fixed video angle and the size of the video file, the successful conversion of the video can be displayed for other players to play.
- 24) full screen display: full screen display.

## 2. Translate



- 1) increase: increase the need to convert video.
- 2) drag the screen, adjust to watch the video angle.
- 3) choose the direction: select the angle of the shot video, respectively, down / up / before.
- 4) video quality: select the quality of the video coding (resolution).
- 5) select mode: select the display of the display angle, respectively, two points screen mode / four sub screen mode / wide-angle mode.
- 6) click Browse to select the stored output path.
- 7) click "start" to start the video conversion.

## 3. Update calibration



- 1) select the file: select the document need to be calibrated.
- 2) automatic calibration: automatic calibration video angle size.
- 3) FOV (video angle): the size of the manual calibration of the video angle, after the completion of the player will be displayed as a standard video angle.
- 4) save into a calibration file.
- 5) exit calibration

#### 4. VeSee Player troubleshooting

- 1) If the video can not play video without any tips or hints, update the graphics driver, please download the driver wizard to update to the latest graphics driver, the graphics driver must support at least OpenGL2.0 and above. Driver wizard address: <http://www.drivergenius.com/>
- 2) Player currently does not support the installation of video playback in the following Windows7 system.